

RINGCENTRAL ROOMS: SETTING UP THE POLY STUDIO X30

RingCentral Rooms combine software with hardware solutions to provide easier deployments and high-quality video conferencing experience. This guide provides an overview of the basic setup of the Poly Studio X30 for RingCentral Rooms.

POLY STUDIO X30 PARTS AND ACCESSORIES

The Poly Studio X30 ships with the following parts and accessories:

- A. Poly Studio X30 video bar
- B. Power supply and cable
- C. Magnetic lens cap
- D. TV mount
- E. LAN cable
- F. HDMI cable

Note: An optional table stand or VESA mount can be ordered separately.



POLY STUDIO X30 BASIC SETUP

Follow these steps to complete the physical setup of the Poly Studio X30:

1. Connect the **LAN cable (E)** from your network to the **LAN port (d)**.
2. Connect the **HDMI cable (F)** from your TV/monitor to the **HDMI Out port (b)**.
3. Connect the power supply cable (B) to the power port (a).
4. Install the **TV mount (D)** to the **TV mount bracket (c)** using the included thumbscrew.
5. Mount the Poly Studio X30 to your TV/monitor.



This completes the initial setup of the Poly Studio X30. Upon boot-up, you are asked to register the device with Poly. You can start the registration process by scanning the QR code displayed on your TV/monitor or by visiting the listed URL.

After you have successfully registered your Poly Studio X30, the TV/monitor displays a pairing code to use on your Poly TC8 Room Controller to complete the sign-in process.

Note: You may be prompted to update your software upon boot-up, follow the prompts to complete the update and the system will display the pairing code after it reboots.

